

PORTAMATRICULAS ADAPTABLE A KAWASAKI Z750/Z1000 07-08' LICENSE SUPPORT ADAPT. TO KAWASAKI Z750/Z1000 07-08' REF:4529N



INSTRUCCIONES DE MONTAJE

- 1- Sacar el asiento delantero , el trasero y el lateral izquierdo del colin. Desmontar la pieza de plastico central que une los laterales del colin, asi como el soporte donde se encuentra el mecanismo de cierre del asiento trasero. Sacar el bloque de instalaci3n electrica que se encuentra anclado mediante dos gomas. Una vez efectuadas estas operaciones, tendremos acceso a los tornillos (6), para aflojar el portamatriculas original.
- 2- Es aconsejable antes de montar el soporte portamatriculas , montar los intermitentes(posici3n 7) y luz de matricula, guiando los cables con las bridas suministradas en las ranuras del soporte.(Esta operaci3n se complica si se efectua con el portamatriculas montado).
- 3- Montar el portamatriculas suministrado, usando los tornillos originales (6) junto a las arandelas (3) y tuercas (5) suministradas, en la posici3n pr3xima a los intermitentes. En la posici3n restante usar los tornillos suministrados (2) junto con las arandelas(3), el casquillo de aluminio(4) y las tuercas (5), tal como indica el croquis adjunto.

INSTRUCTIONS TO ASSEMBLE

- 1- Remove the front and rear seat, and the left part of the rear cowl. Dismount the central plastic piece that joins together both sides of the rear cowl, as well as the support where the mechanism to lock the rear seat is located. Remove the electrical installation that is fixed through two rubber bands. Once this is done, we will have access to the fasteners (6) to remove the original license support.
- 2- It is recommended that before mounting the original support, the turn signals (position 7) and license light are mounted. Guide the cables with the bridles supplied through the slots of the support (this operation gets complicated once the license support is mounted).
- 3- Mount the license support supplied, using the original fasteners (6) jointly with the washers (3) and nuts (5) supplied, on the position close to the turn signals. On the other positions, use the fasteners supplied (2) jointly with the washers (3), and the metal arrowhead (4), and nuts (5), as the figure shows.

Material suministrado para el montaje en la motocicleta:

Material supplied to assemble the license support:

POSICI3N	DENOMINACI3N		CANTIDAD
1	Soporte portamatriculas	License support	1
2	Tornillo M6X40 DIN933 blanco	M6x35 DIN933 white fastener	2
3	Arandela M6 DIN9021 blanco	M6 DIN9021 white washer	6
4	Casquillo de aluminio	Aluminium arrowhead	2
5	Tuerca M6 grafilada DIN6923	M6 DIN6923 locknut	4
7	Bridas de plastico	Plastic bridles	4
8	Catadioptrico	Reflector	1
9	Desplazador catadioptrico	Support for reflector	1
10	Luz portamatriculas	Light	1

